マクソン ACアダプタ

モデル	λカ	出 カ	主な対応国	極 性
AC2009*1	100VAC to 240VAC	9VDC/2000mA	ワールドワイド	
AC210N	120VAC		米国、カナダ	
AC210U	220VAC	9VDC/200mA	英国を除くヨーロッパ	⊕-€-⊖
AC210UK	230VAC		英 国	center-/sleeve+
AC210	100VAC	9VDC/200mA	日本	
AC310	100VAC	9VDC/300mA	日本	

AC2009はモデル番号の末尾に追加する文字によってACコードのプラグタイプが異なります。 注文の際は必ずモデル番号の末尾に文字を追加してください。

追加文字	主な対応国	追加文字	主な対応国
J	日本	UK	英国
N	米国、カナダ	AN	オーストラリア、ニュージーランド
U	フランス、ドイツ、スイス、ベルギー、オランダ、	K	韓国
	イタリア、オーストリア、ノルウェー、デンマーク、	C	中国
	スウェーデン、フィンランド		

お客様または第三者が、この製品の誤った取り扱い、故障、その他の不具合、またはこの製品の使用によって受けられた損害については、法令上の賠償責任が認められる場合を除き、当社は一切その責任を負いません。あらかじめご了承ください。

本製品の故障、誤動作または不具合による、コンサートやイベントなどにかかわる損害、及びお客様または第三者が製品利用の機会を逸したために発生した損害など、付随的損害の補償については、当社は一切責任を負いません。あらかじめご了承ください。



株式会社 日伸音波製作所

〒390-0851 長野県松本市島内4172番地1

TEL: 0263-40-1403 FAX: 0263-40-1410 www.maxon.co.jp

製品仕様及び製品外観などは、改良のため予告なく変更することがあります。

●安全上のご注意● 必ずお守りください

機器を安全にご使用いただくため、ご使用前にこの取扱説明書を 必ずお読みください。

そのあとは大切に保管し、必要になったときにお読みください。 製品を安全に正しくお使いいただくために、必ずお守りいただく ことを次のように区分して説明しています。

●表示内容を無視して誤った使い方をしたときに、生じる危害や損害の程度を次の表示で区分し説明しています。

▲ 数 生

この表示欄は、「人が死亡または重傷などを負う可能性 が想定される」内容を示しています。

⚠ 注意

この表意欄は、「傷害を負う可能性または物的障害のみ が発生する可能性が想定される」内容を示しています。

●お守りいただく内容の種類を、次の絵表示で区分し、説明しています。



.... このような絵表示は、気をつけていただきたい 「注意喚起」 の内容を示しています。





..... このような絵表示は、してはいけない「禁止」の内容を示し ています。





..... このような絵表示は、必ず実行していただく「強制」の内容 を示しています。



ケースを絶対に開けないでください。

機器の裏蓋を開けて改造しないでください。 《内部には電圧の高い部分があり、火災や感電の危険があります。》



異常のときは機器の使用を中止してください。

煙が出たり、変な臭いや音がする場合、機器の使用を中止してください。直ちにコンセントからACアダプタを抜いてください。点検、修理をご依頼ください。



取扱説明書

/A Maxon

UMN-FZ2-0201A Copyright ©1999-2013 NISSHIN ONPA CO., LTD. Allright reserved. August 2013 Printed in Japan.

▲ 警告



放熱にご注意



ACアダプタを布や布団等で覆ったり、包まないでください。 《熱がこもり、ケースの変形や火災の危険があります。》

注意



指定以外のACアダプタを使わない。

必ず指定のAC100ボルト用のACアダプタをご使用ください。 《指定以外のACアダプタを使用しますと火災、感電の原因になることがあります。》



電源プラグの抜き差しは正しく

ぬれた手でACアダプタを抜き差ししないでください。 《感電の危険があります。》

コンセントから抜くときは、必ずACアダプタ本体を持って抜いてください。

ペコードの部分を引っ張りますと、コードが傷つき、火炎や感電の原因になることがあります。》



水、湿気、ほこり、高温は禁物

風呂場や屋外など水のかかる所、湿度が高い所、ほこりの多い所、温度の高いところでは保管や使用をしないでください。 《火災や感電の原因になることがあります。》



長期間使用しないときは

長時間使用しない場合は、必ずACアダプタ/電池を外してください。 《火災の原因になることがあります。》

FWA10 Fuzz Elements Water 水

- パワー・コードを弾いても潰れすぎない適度な飽和感を持ち、周波数帯 域とレベルを調整するパラメトリック・イコライザ機能を装備したハイブリ ッド・ファズ。
- ●中音域をカットしたスクープ・サウンドを始め、低音域や高音域にメリハ リを与るなど、TONEコントロールと合わせて幅広い音作りが可能です。
- 3PDTメカニカル・スイッチによるTBS(True Bypass Switching)採用。
- ●LEDの点灯によりエフェクト効果のON/OFFが一目で確認できます。ま た、バッテリー・コンディションも兼ねています。

各部の名称と使い方

①INPUT (インプット・ジャック) 入力ジャックです。ギターや他のエフェク ター等の楽器、機器類の出力と接続しま す。ブラグを差し込むと、自動的に電源が 入ります。使用しない時はプラグをジャッ クから抜いておいてください。

2 OUTPUT

(アウトプット・ジャック)

出力ジャックです。アンプまたは他のエフェクターなどの入力と接続します。

(3)SUSTAIN

(サスティーン)

(サスティーン) ひずみの量とサスティーンの幅をコントロールします。 右へ回すとひずみが増し、 サスティーンの幅が広くなります。

4TONF

音質をコントロールします。右へ回すと高 音域が強調され、左に回すと低域が強

(5)EQ B/C

(イコライザ ブースト/カット) パラメトリック・イコライザのレベルを調整 します。右へ回すとブースト、左へ回すと カットします。センターでフラットになりま

6FQ FRFQ

(イコライザ周波数) パラメトリック・イコライザの 周波 数を 100Hzから5kHzの間で設定します。左に回しきると周波数が100Hz、右に回すに従 って周波数が高くなり5kHzまで連続可変 できます。センターでおよそ600Hzです。

(7)LEVFL

(レベル)

出力音量をコントロールします。通常は バイパスとエフェクトの音量が同じになる ようセットします。

⑧フット・スイッチ

(バイパス/エフェクト スイッチ) パイパス/エフェクト切り換えるスイッチ 踏む度にエフェクト(LEDが点灯) イバイパス(LEDが消灯)します。

9INDICATOR

(バイパス/エフェクトLEDインジケ エフェクトの状態でLED点灯/バイパスの 状態で消灯します。 バッテリー・コンディ ションも兼ねています。

暗い場合や点灯しない時は、電池が入 へてないか、電池が消耗(電圧が低下) しています。新しい電池と交換してくだ


10DC · INPUT

(外部電源入力ジャック) 専用ACアダプタを接続するジャックです。

ACアダプタやDCプラグを抜き差しする ↑ 前にアンプのボリュームを最小にしてく ださい。

. ● 9V バッテリ、または9Vのオプション・パワーサプライで動作します。

● 純日本製 / MADE IN JAPAN



電池交換

- ●この製品は9V乾電池6F22を1本使用しています。
- 乾電池の交換は図の手順に従ってください。




※乾電池の交換はバッテリ・スナップと乾電池の接続が確実であること、 乾電池の極性に注意してください。

※使用済み乾電池は、住んでいる市町村の指示に従って、廃棄してくだ

取扱上の注意

- ■ギター、エフェクタ、アンプ等へのプラグ接続は、接続されるほかの機器へ のノイズによる損傷を防ぐためにエフェクタ、アンプ等のボリュームを絞り 切ってから接続してください。
- 乾電池を長持ちさせるため、使用しない時は、インプット・ジャックからプラ グを抜いてください。
- ■長時間使用しない時は、乾電池を抜きとってください。
- LEDが暗くなったり点灯しない時は乾電池の電圧低下を示します。このよ うな場合効果が弱くなったり音がひずんだりしますので早めに乾電池を交 換してください。
- ACアダプタは必ずマクソン製品をお使いください。指定外のものをご使用 になるとトラブルの原因になります。
- ■操作上必要なもの以外の止めネジ類には触れないでください。





主な仕様

入力インピーダンス · 100k O 出力インピーダンス -100k Ω 最大增幅率 :80dB (600Hz)

入力換算ノイズ (IHF-A) :-115dB以下(入力ショートIHF-A)

コントロール : SUSTAIN, TONE, LEVEL, EQ B/C, EQ FREQ.

スイッチ :BYPASS/EFFECT 表示 :BYPASS/EFFECT LED

雷源 :6F22 9V乾電池1本または専用ACアダプタ

:15mA/9VDC 消費電流

電池寿命 :マンガン 25時間 25℃(FUJITSU 6F22) :アルカリ 45時間 25°C(TOSHIBA 6LF22)

寸法(突起物含む) : 70mm (幅)×113mm (奥行き)×56mm (高さ)

重量 :330g(乾雷池含む) 同梱品 :テスト用乾電池×1

製品保証書×1 取扱説明書×1

%0dB=0.775Vrms

※規格及び外観は改良の為予告なく変更する場合があります。

Optional accessories: Maxon AC adaptor

model name	input	output	country	polarity
AC2009*1	100VAC to 240VAC	9VDC/2000mA	worldwide	
AC210N	120VAC		USA, Canada	
AC210U	220VAC	9VDC/200mA	Europe (except UK)	⊕-€-⊖
AC210UK	230VAC		UK	center-/sleeve+
AC210	100VAC	9VDC/200mA	Japan	
AC310	100VAC	9VDC/300mA	Japan	

Plug type of AC2009 varies with the suffix as shown below. Please specify exact model (like AC2009AN, AC2009C) when ordering.

suffix	country	suffix	country
AN	Australia, New Zealand	U	Austria, Belgium, Denmark,
C	China		Finland, France, Germany, Italy,
J	Japan		Netherlands, Norway, Sweden,
K	South Korea		Switzerland, etc.
N	USA, Canada	UK	UK



If you want to dispose this product, do not mix with general household waste.

There is a separate collection system for used electronics products in accordance with legislation under the WEEE Directive (Directive 2002/96/EC) and is effective only within European Union.

FCC Class B Equipment, United States Only.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit that is dfferent from that to which the receiver is connected.

 Consult the dealer or an experienced radio or television technician for help.

Declaration of conformity for products marked with the FCC logo, United States only. This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

For questions regarding this FCC declaration, contact us by mail, phone or e-mail: MAXON United States distributor:

Godlyke, Inc. P.O. Box 3076 Clifton, NJ 07012 USA Phone: 973-777-7477

E-mail: info@godlyke.com MAXON / NISSHIN ONPA CO., LTD.

E-mail: sales@maxon.co.jp
To identify this product, refer to the model number found on the product.



SAFETY PRECAUTIONS Please be sure to observe.

The safety precautions listed below are intended to ensure your safety whenever you use the equipment.

Precaution text is generally accompanied by the following symbols to alert you and others to the risk of personal and material injury that may be caused if the precaution is ignored.



This symbol indicates an item that can result in death or serious personal injury if ignored.



This symbol indicates an item that can result in serious personal injury or material damage if ignored.

■ Precaution text is generally accompanied by the following icons to alert you and others to things you should or should not do.



A triangle indicates something you should be careful about.



A circle with a line through it indicates something you should not do.



...... A black circle indicates something you must do.

🗥 Warning




NEVER OPEN THE CASE

Never try to remove the bottom cover and to modify the equipment. (Internal components of the equipment use high voltages, and exposing them creates the danger of fire and electrical shock.)



STOP THE USE IN CASE OF A PROBLEM



Contact your original dealer or nearest authorized service provider for service.



FWA10 ELEMENTS • User's Guide

♦SAFETY PRECAUTIONS **♦**

To assure safe operation of the equipment, please make sure to read these precautions prior to use.

Keep this User's Guide on hand for future reference whenever you need it.

Maxon shall not be held liable to you or any third party for any losses caused by incorrect operation of this equipment, malfunction or any other failure of this equipment to operate as expected, or normal use of this equipment, except to the extent stipulated by law.

Maxon shall not be held liable to you or any third party for any losses related to concerts, exhibitions, or any other type of event due to malfunction or incorrect operation of this equipment.

NISSHIN ONPA CO., LTD.

4172-1 Shimauchi, Matsumoto-City, Nagano, 390-0851 Japan

TEL:+81-263-40-1403 FAX:+81-263-40-1410 www.maxon.co.jp sales@maxon.co.jp

For North America

www.maxonfx.com info@maxonfx.com

UMN-FZ2-0201A Copyright ©1999-2013 NISSHIN ONPA CO., LTD. Allright reserved. August 2013 Printed in Japan.

ALL SPECIFICATIONS ARE SUBJECT TO CHANGE FOR IMPROVEMENT WITHOUT NOTICE OR OBLIGATION.

⚠ Warning



BEWARE OF HEAT BUILD-UP

Never cover AC adaptor with cloth or other objects. «Build up heat creates the danger of the equipment deformation and fire.

⚠ Caution



USE SPECIFIED AC ADAPTOR ONLY

· Be sure to use only the AC adaptor specified in this User's Guide. Use of non-specified AC adaptors creates the danger of fire and electrical shock



UNPLUGGING AC ADAPTOR

- Never try to unplug AC adaptor while your hands are wet. Doing so creates the danger of electrical shock. When unplugging AC adaptor from the power source, be sure to
- grasp the adaptor. Never pull on the cord. Doing so can damage the power cord and create the danger of fire and electrical shock.



WATER, HUMIDITY, DUST AND HIGH **TEMPERATURES**

Never leave or use the equipment in bathrooms, the outdoors or other areas subject to water, high humidity, dust and high temperature. Doing so creates the danger of fire and electrical



LEAVING THE EQUIPMENT UNATTENDED

Whenever leaving the equipment unattended for long periods, be sure to unplug AC adaptor from the power source. If not, there is a danger of fire

FWA10 Fuzz Elements Water 水

- The FWA10 expands on the classic fuzz/distortion sounds of FEA10 by adding a parametric tone section to the circuit.
- By selecting a specific frequency and boosting or cutting it accordingly, a wide array of new and unique guitar tones can be created including scooped midrange, hi-boost, low-boost, etc.
- True Bypass Switching lets your instrument's signal pass through a non-electronic bypass line when the effect is disengaged, feeding your amp with direct, unaltered signal from vour instrument.

FEATURES AND CONTROLS



①INPUT(input jack)
Input jack to connect to the output of guitar, other effects or related equipment. The product automatically turns on when a plug is inserted into this jack. When not in use, disconnect plug from input iack to preserve battery life.

@OUTPUT(output jack)

Output jack to connect to input of amplifier or other effects.

3SUSTAIN

Controls the amount of Distortion and Rotate this clockwise for deep distortion and long

4)TONE

the amount of high/low es - Turn this knob clockwise Controls frequencies more high frequencies counterclockwise for more frequencies.

SEQ B/C

(Equalizer Boost/Cut)

Controls the level of Parametric Equalizer - Turn this knob clockwise for Boost and counterclockwise for Cut. When set at center detent position, it provides +/-0dB Boost/Cut (flat response).

©EQ FREQ

(Equalizer frequency)

Controls the frequency of parametric equalizer, which is continuously variable from 100 Hz to 5 kHz. When set to full clockwise, it provides 5 kHz frequency. When set to full counterclockwise. provides 100Hz frequency. When set to the center position, it provides 600Hz

Controls output level of effected tone Typically output levels of both normal and effected tone should be adjusted to equal levels.

®FOOTSWITCH

(bypass/effect switch)

Switch for effect on/off. Stepping on this switch alternately turns effects on (LED on) and off (LED off).

9INDICATOR

(bypass/effect LED indicator)

The LED lights when effect is on. The light is turned off at bypass status. LED brightness synchronizes with battery


No LED light indicates the battery is low or not installed. In this case replace the battery.

10DC INPUT (power input jack)

Jack for connection of external power supply to effect.



CONNECTION DIAGRAM



SPECIFICATIONS

: 100k ohms Input Impedance Output Impedance : 100k ohms Maximum Gain : 80dB (600Hz)

Input Noise : -115dB or less (Input shorted, IHF-A weighted) Controls : SUSTAIN, TONE, LEVEL, EQ B/C, EQ FREQ.

: BYPASS/FFFFCT Switch : BYPASS/EFFECT LED Indicator

Power Supply : 6F22/6LF22 9V battery x 1 or Maxon AC adaptor

: 15mA max. / 9VDC Power Consumption

: 9VDC manganese battery 25 hours 25 deg C (FUJITSU 6F22) Battery Life

: 9VDC alkaline battery 45 hours 25 deg C (TOSHIBA 6LF22)


Dimensions : 70(W)×113(D)×56(H)mm (with protrusion)

Weight : Approx. 330g (incl. battery)

Accessory : 6F22 9V battery x 1, operating manual

*0dB=0.775Vrms

- LED to indicate bypass/effect and battery condition for trouble-free performance.
- Operates with 9V battery or standard AC adaptor for 9V (not included)
- Made in Japan.



BATTERY REPLACEMENT

FWA10 operates on one 9V battery (6F22 or 6LF22). Follow the procedures below to replace a battery.



* Be sure the battery is firmly connected to battery snap with the correct polarities.

ATTENTION:

- Turn down the volume of effect and amplifier to the minimum before connecting Maxon effects to guitar, amplifier or other effects in order not to damage other connected equipment by unintended noise.
- When not in use, disconnect plug from input jack to preserve battery.
- Take out the battery if the product is not used for a long period of time.
- No or dark LED light indicates the battery is low or not installed. In this case replace the battery to avoid poor effect or distorted signal.
- Be sure to use the correct Maxon AC adaptor. of any other adaptor may cause trouble.
- Do not try to remove screws.

^{*}All specifications are subject to change for improvement witho notice or obligtion.